



CLEAR COAT

Technical data sheet



APPLICATION SEQUENCE FOR LAQUER CLEAR COAT

5	Clean with Laquer Cleaner
4	For a complete dry time wait 12 hours
3	3 th Wet Coat (wait 12 hours before chrome application)
2	2 nd Wet Coat and wait 5 minutes
1	1 st Dry Coat and wait 5 minutes
	Model surface



www.modelinnovations.co.uk

made in italy



COLORS
custom paint industries