



CLEAR COAT

Technical data sheet



XW100 APPLICATION SEQUENCE

5	Clean with Kcleaner WB
4	For a complete dry time and for best resistant to white spirit or Enamel wait 12 hours
3	Apply another wet coat (dry time 3 hours)
2	Apply 1 wet coat (dry time 5 minutes, not 4 not 6, just 5)
1	Apply 2 dry coat (dry time 5 minutes, not 4 not 6, just 5)
	Model surface

APPLICATION SEQUENCE FOR ALL OTHERS CLEAR COAT WB

5	Clean with Kcleaner WB
4	For a complete dry time wait 6/7 hours
3	3 th Wet Coat (wait 3 hours before chrome application)
2	2 nd Wet Coat and wait 10 minutes
1	1 st Dry Coat and wait 10 minutes
	Model surface



www.modelinnovations.co.uk

made in italy



COLORS
custom paint industries